

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-1



CHR-2



CHR-3



CHR-4



CHR-5



CHR-6



CHR-7



CHR-8

CHR-2

1 3/4"

CHR-3

1 3/4"

CHR-4

1 1/2"

CHR-5

2 1/4"

CHR-6

2 1/2"

CHR-7

2 1/2"

CHR-8

1 5/8"

CHR-1

4"



CHR-9



CHR-10



CHR-11-A



CHR-12-A



CHR-13



CHR-14



CHR-15

CHR-9

2 3/4"

CHR-10

1 7/8"

CHR-11A

3 3/4"

CHR-12A

2"

CHR-13

2 1/2"

CHR-14

2 1/2"

CHR-15

2 3/4"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-17

CHR-17

2"



CHR-18

CHR-18

2 5/8"



CHR-19

CHR-19

3 3/8"



CHR-20

CHR-20

2 1/2"



CHR-21

CHR-21

2 1/2"



CHR-22

CHR-22


1 5/8"



CHR-23

CHR-23

3 3/8"



CHR-24

CHR-24

1 11/16"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-25



CHR-26



CHR-27



CHR-28



CHR-29



CHR-30

CHR-25

2 7/8"

CHR-26

3 1/8"

CHR-27

2 1/16"

CHR-28


2"

CHR-29

1 5/8"

CHR-30

3"



CHR-31

CHR-31

6"



CHR-32

CHR-32

5 1/2"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK

100



CHR-33  
3 1/8"

CHR-34  
2 1/2"

CHR-35  
3"

CHR-36  
3 1/2"

CHR-37  
3 7/8"