

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-2

CHR-3

CHR-4

CHR-5

CHR-6

CHR-7

CHR-8

1 3/4"

1 3/4"

1 1/2"

2 1/4"

2 1/2"

2 1/2"

1 5/8"

CHR-1  
4"



CHR-9

CHR-10

CHR-11A

CHR-12A

CHR-13

CHR-14

CHR-15

2 3/4"

1 7/8"

3 3/4"

2"

2 1/2"

2 1/2"

2 3/4"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-17

CHR-17

2"



CHR-18

CHR-18

2 5/8"



CHR-19

CHR-19

3 3/8"



CHR-20

CHR-20

2 1/2"



CHR-21

CHR-21

2 1/2"



CHR-22

CHR-22


1 5/8"



CHR-23

CHR-23

3 3/8"



CHR-24

CHR-24

1 11/16"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK



CHR-25



CHR-26



CHR-27



CHR-28



CHR-29



CHR-30

CHR-25

2 7/8"

CHR-26

3 1/8"

CHR-27

2 1/16"

CHR-28


2"

CHR-29

1 5/8"

CHR-30

3"



CHR-31

CHR-31

6"



CHR-32

CHR-32

5 1/2"

# CHAIR RAIL

BRUNSELL LUMBER & MILLWORK

100



CHR-33



CHR-34



CHR-35



CHR-36



CHR-37

CHR-33

3 1/8"

CHR-34

2 1/2"

CHR-35

3"

CHR-36

3 1/2"

CHR-37

3 7/8"