

CROWN HEAD MOULDING

BRUNSELL LUMBER & MILLWORK

87



CR HEAD-1



CR HEAD-2



CR HEAD-3

CR HEAD-1

1 3/8"x 2 3/8"

CR HEAD-2

1 1/8"x 2 1/4"

CR HEAD-3

1 3/4"x 1 1/2"



CR HEAD-4



CR HEAD CASING-5



CR HEAD CASING-6

CR HEAD-4

1 5/8"x 2 3/4"

CR HEAD-5

1 3/8"x 3"

CR HEAD-6

1 3/8"x 2"

CROWN HEAD MOULDING

BRUNSELL LUMBER & MILLWORK



CR HEAD-7



CR HEAD-8



CR HEAD-9

CR HEAD-7

1 1/8" x 2 5/8"

CR HEAD-214

1 3/4" x 1 5/8"

CR HEAD-9

1 1/8" x 2-1/4"



CR HEAD-10




CR HEAD-11

CR HEAD-10

1 3/8" x 2 1/2"

CR HEAD-11

1 3/8" x 1 7/8"




CROWN HEAD MOULDING

BRUNSELL LUMBER & MILLWORK



CR HEAD-12



CR HEAD-13



CR HEAD-14

CR HEAD-12

1 1/8" x 2 5/8"

CR HEAD-13

1 3/4" x 1 5/8"

CR HEAD-14

1 1/8" x 2-1/4"



CR HEAD-15



CR HEAD-16



CR HEAD 2 1/4



CR COVE/BEAD

CR HEAD-15

1 3/4" x 2 1/8"

CR HEAD-16

1 5/8" x 1 3/4"

CR HEAD-214

1 7/8" x 1 5/8"

CR HEAD-COVE/BEAD

2 1/4" x 2"